

en ahlsell

Installation instructions

Threaded check and foot valves

AVI 1630





Assembly instructionThreaded check and foot valves

This instruction apply to check valves AVI 1630 (picture 1) and foot valves AVI 1630 (picture 2)

Area of use

Domestic water, heating/cooling system, And certain oils that do not damage the components included.

Installation

- The valve can be mounted in any position.
- Note the flow direction arrow on the valve body.
- The valve must be mounted with a wrench or fixed key. Pipe pliers or similar can pinch close the valve so that the non-return valve insert engages the valve housing.

Maintance

The valve is maintenance-free under normal conditions operating conditions, filter basket on bottom valve however, must be cleaned and replaced if necessary.

The product is construction product rated.



Bild 1



Bild 2



